



<i>Your Pathway to Better Protection Against Wildfire</i>	Wildfire Prepared Home	Wildfire Prepared Home Plus
Create and maintain the 5-foot buffer	•	•
Ensure roof is Class A fire-rated	•	•
Choose noncombustible gutters and downspouts	•	•
Clear roofs, gutters, and downspouts of debris	•	•
Install ember-resistant vents	•	•
Ensure a 6-inch ground clearance for exterior walls	•	•
Clear and maintain decks and covered porches	•	•
Maintain defensible space	•	•
Remove combustible fencing within 5 feet of the home	•	•
Keep accessory structures compliant	•	No structures within 30 feet of home
Cover gutters		•
Enclose underside of eaves		•
Install metal dryer vent		•
Install a noncombustible exterior wall cover		•
Ensure shutters, if in place, are noncombustible		•
Upgrade to fire-resistant windows		•
Upgrade to noncombustible exterior doors		•
Enclose the space underneath bay windows		•
Upgrade to a noncombustible deck		•
Remove back-to-back fencing		•

For more information, visit www.wildfireprepared.org